

# RIDIG CORE MAX 22

## Waterproof – Stone Composite Flooring

Drop-Lock Easy Installation / Scratch & Stain Resistant / Pre-Attached Acoustics Pad

Size 7" x 48" / 5mm Total Thickness / SPC (Stone Polymer) Composition / 1mm IXPE Pre-Attached Pad

Ultra Scratch, Stain and Wear Resistant Shield / Double UV Coating / 22 mil Wear Layer

### Tools Required

Utility Knife, Tape Measure, Rubber Mallet, Tapping Block, ¼" spacers.

Optional equipment – Table Saw, Chop Saw, Carpenter Square

### Installation

- 1) Inspect all planks for defect and damage. Do not install damaged planks. Use them for cuts during installation. If debris gets into the grooves, clean and remove.
- 2) Planks are laid left to right. Start at the left wall of the room and work towards the right side. The tongue side of the plank should face the starting wall.
- 3) It is a good idea to put at least ¼" spacers along the wall.
- 4) As you work from left to right, drop and lock the short sides of each plank, using a rubber mallet.
- 5) The last plank on the right will need to be cut. Score the plank with a sharp utility knife and a carpenter square. Then snap it. You can also use a table saw or chop saw to make the cut. The remaining piece will be your starter piece for the next row. But make sure the joints are staggered at least 8". Joints from one row to the next should always be staggered a minimum 8"
- 6) When you start a new row, angle the long side of the plank with the tongue going into the groove of the previous row. When placed, use a rubber mallet and a tapping block to make sure the long side has engaged properly. Install the second plank in the row the same way. Then slide and drop over the short side to lock in place. Use a rubber mallet again to make sure the short side is engaged.

## After Installation

- 1) Remove spacers and install transition molding. Do not fasten moldings to the planks. Transition moldings should be fastened to the subfloor and wall trim should be fastened to the wall.
- 2) Use proper floor protectors / coasters under legs of all furniture.
- 3) Do not use any polishers, waxes or harsh chemicals for cleaning.
- 4) Most flooring and furniture will be affected by prolong periods of sunlight. If possible, use drapes on windows to reduce UV exposure.

## Warranty

25 years residential, 10 years light commercial.